


## DT-103G Quick Installation Guide

### Step 1. Insert the SIM card

**Warning: Please DO NOT connect the power jack to the DT-103G before SIM card insertion**

- Orientated the SIM card with metal contacts upwards and insert completely into DT-103G
- If you want to remove the SIM card, you should use some special tools such as forceps to take it out



Metal contacts upwards

### Step 2. Insert the external antenna

- Connect the SMB side of the Antenna adapter cable to the DT connector mark with Ext. Ant.
- Connect the FME connector with the external antenna



### Step 3. Power up the DT-103G and notice the LEDs

- Power up the DT-103G by inserting the power jack, the supply should be 12VDC, 1A
- DT-103G initiation state and LED status are shown in the following diagram

